

Product Specification (Rev. A)

EZ Check Scanner Kit

Product Name: EZ Check Scanner Kit
Item Number: K2-KCIS
Style: Kit

Product 1 Description: EZ Check Scanner Cleaning Cards
Product 1 Part #: K2-CIB25
Product 1 Quantity: 25 Cards

Product 2 Description: SNAP Swabs 4" / 101.6mm IPA Filled Reservoir Handle
Product 2 Part #: K2-SPSN1
Product 2 Quantity: 6 Swabs

Special Features: N/A

Packaging: **Inner Pack**
Quantity: 1 Kit
Labeling: Labeled Box
Package type: Clay Coated Chipboard Box
Inches (H x W x D): 10" x 5" x 1.5"
mm (H x W x D): 254 x 127 x 38.1 mm
Weight: .92 lbs
Weight Kilograms: .418 kg
Cubic Ft: N/A
Cubic Meters: N/A
Kits per unit: 1 Kit
UPC Code: 644218130380

Master Casing
44 Kits

Corrugated (200 lb test)
16" x 16" x 16"
406.4 x 406.4 x 406.4 mm
43 lbs
19.522 kg
2.37 cf
.067 cm
44 / Carton

Palletizing
Quantity: 24 Master Cartons
Inches (H x W x D): 69" x 40" x 48"
mm (H x W x D): 1752.6 x 1016 x 1219.2 mm
Weight Lbs: 1062 lbs
Weight Kilograms: 483.148 kg
Cubic Ft: 76.67 cf
Cubic Meters: 2.17 m3
Kits per unit: 1056 / Pallet

Product Specification (Rev. A)

Epson CaptureOne Cleaning Kit

Kit Label - Front

99.7% IPA

Check Scanner Cleaning Kit



This Check Scanner Cleaning Kit is designed to maintain the clarity of your check scans simply and effectively.

Contents:

- 25 Check Scanner Cleaning Cards
- 6 “Snap” Cleaning Swabs

Made in the U.S.A.



6 44218 13038 0

Kit Label - Back

99.7% IPA

Check Scanner Cleaning Kit



Directions:

- Carefully remove Cleaning Card from pouch.
- To clean the magnetic head and camera lens plates, insert card into scanner hopper then command a scan cycle and allow card to pass through the scanner. Lift card from output stacker and place into hopper, then command another cycle. Flip card top to bottom then repeat process two more times to achieve maximum usage from the card.
- To clean input drive rollers, insert card into hopper while holding onto the trailing end. Command scan cycle, then allow rollers to turn against card. Repeat again after flipping card end to end.
- Dispose of card properly in waste receptacle.
- Use “Snap” Cleaning Swab to remove any visible dirt particles along scanner hopper. Simply squeeze the end of the swab tube until you feel it snap and the solution will saturate the swab head.