

Product Specification (Rev. C)

SNAP Swabs 4"/101.6mm IPA Filled Reservoir Handle



Product Name: SNAP Swabs 4"/101.6mm IPA Filled Reservoir Handle
Item Number: K2-SPSZ25
Style: Swab with IPA Filled Reservoir

Swab Length Inches: 4"
Swab Length mm: 101.6 mm

Solution: 91% IPA / 9% Deionized Water
Volume: 1.4ml

Special Features: Snap swab handle at end of reservoir, IPA will saturate swab head

Packaging:
Quantity: 25 Snap Swabs
Labeling: Labeled Bag
Package type: Zip Bag
Inches (L x W x H): 7" x 5"
mm (L x W x H): 177,8 x 127 mm
Weight: .10 lbs
Weight Kilograms: .05 kg
Cubic Ft: N/A
Cubic Meters: N/A
Swabs per unit: 25 / Zip Bag
UPC Code: 644218120909

Master Casing
100 Zip Bags

Corrugated (200 lb test)
16" x 16" x 8"
406,4 x 406,4 x 203.2 mm
13.5 lbs
6.13 kg
1.19 cf
.034 m3
2,500 / Carton

Palletizing
Quantity: 36 Master Cartons
Inches (L x W x H): 48" x 40" x 53"
mm (L x W x H): 1219,2 x 1016 x 1346,2 mm
Weight Lbs: 516 lbs
Weight Kilograms: 234.26 kg
Cubic Ft: 58.89 cf
Cubic Meters: 1.67 m3
Swabs per unit: 90,000 / Pallet

7/20/11 2:56 PM

Product Specification (Rev. C)

SNAP Swabs 4"/101.6mm IPA Filled Reservoir Handle




Front of Pouch N/A

Back of Pouch N/A


Bag Label

91% IPA

Snap Swab™



25 Swabs




The snap swab can be used to clean print heads, paper paths, guides and rollers. Swab stem holds cleaning solution of 91% IPA and 9% de-ionized water. This will safely and effectively remove all contaminants.

Recommended Usage:
As Often as necessary. OEM's recommend at least every time you change your paper stock.

Directions:

1. Place swab stem between thumb and index finger and "snap".
2. Solution will saturate the foam tip.
3. Wipe across print head 6-8 times.
4. Properly dispose of.

Made in U.S.A.



6 44218 12090 9

Easy • Effective • Safe